




GOBUDS 410

PRODUCT DESCRIPTION



- 1 Microphone
- 2 Multifunction button
- 3 LED indicator
- 4 Type C Interface



HOW TO WEAR



Gently insert the earbuds into the cochlea and adjust it to a proper angle.
(L for left earphone, R for right earphone)

- Find the Bluetooth device: GOBUDS 410 and connect it, and there will be a prompt tone after the successful connection.

(Note: If GOBUDS 410 cannot be found, please confirm whether the earphone is turned on or you can turn off the Bluetooth of the mobile phone and then turn it on again.)



FUNCTION INTRODUCTION

MFB

Pick up/hang up the phone	Press the multifunction button
Decline a call	Long press the multifunction button for 2 seconds
Music play / pause	Press the multifunction button
Last song	Double click the left earphone multifunction button
Next song	Double click the right earphone multifunction button
Lower the volume	Long press the left earphone multifunction button
Increase the volume	Long press the right earphone multifunction button
Siri or voice assistant	Three click the multifunction button

Charging

- Earbuds charging: put the headset back into the charging case and close the cover to charge the earphone.
Charging: white light on,
Fully charged: white light off.
- Charging of the charging case: connect Type-C charging cable to charge.
Charging: white light flash.
Fully charged: white light on.

Power on / off

- Power on:
 - Take out the earphone from the charging case, and the earphone will turn automatically.
 - If it doesn't turn on automatically, press and hold the headset multifunction button for 5 seconds to turn it on.
- Power off:
 - Put the earphone into the charging case and close the cover, and the earphone will turn off automatically.
 - When music is not playing, press the headset multifunction button for 5 seconds.

Headset pairing

- After the two earphone are taken out of the charging case or turned on, the left and the right headset will pair automatically and enter the connection mode with the device.
- Turn on Bluetooth of the phone and search for Bluetooth devices.

PRODUCT PARAMETERS

Model: GOBUDS 410

Bluetooth version: V5.0

Wireless range: > 10m {in barrier-free environment}

Input voltage: 5VDC,1A.

Earbud battery: 50mAh X2

Battery of charging case: 350mAh

Charging time: 1-2h

Talk time/ Music time: 5-6 hours (at 70% Volumned)

Standby time: 100 hours

Water Resistance: IPX5

Long Battery Life upto 20 hours including the charging case.

ATTENTION

- Please use it in a room without wall –like barriers, otherwise it may cause sound stuck/ interruption.
- The distance between the headset and the device should not be too far, otherwise the sound may be stuck / interrupted.
- If there are a lot of wi fi and 4g signals around or other high-power electrical appliances when using, it is easy to cause sound stuck/ interruption.

FAQ

- Q: how to solve the problem that only one earphone can listen to music?
A: put the two earphone back into charging box and close the cover, take them out again to check whether the binaural mode is restored, if the earphones have not recovered, you can clear the pairing information to solve the problem.
- Q: what should i do if the phone says “cannot connect”?
A: delete the pairing record on the phone, and then search and connect again to solve it.

The logo for GOVO, featuring the word "GO" stacked above "VO" in a bold, light blue, sans-serif font.